



PLASTICS RESEARCH LABORATORIES, INC.  
MOLD RELEASES & PROCESS ADDITIVES

Mailing: Box 77 0855 Woodside, NY 11377 USA  
Shipping: 58-20 Broadway, Woodside, NY 11377 USA  
Phone: 718-672-8300 • Fax: 718-565-7447  
E-mail: info @axelplastics.com

[www.axelplastics.com](http://www.axelplastics.com)

Technical Data Sheet

**MoldWiz®**

**INT-PUL29**  
Internal Mold Release  
Process Aid Additive

**Product Description**

A liquid internal mold release/process aid additive which is incorporated directly into the resin to provide release from the die in pultrusion processing. Will also: improve line speed; reduce pull force; enhance wetting of reinforcements and fillers; and improve the surface appearance of molded profiles.

An effective addition of process aid additive will not have any adverse effect on the cured resin or interfere with secondary operations such as printing, painting or bonding of cured parts.

May also be used as an internal mold release in other processes that utilize polyester, vinyl ester and hybrid thermoset resin systems.

**Composition**

A proprietary synergistic blend comprising organic fatty acids, esters and amine neutralizing agents.

**Handling**

Keep container closed when not in use.  
Store above freezing and below 100°F / 38°C.  
DO NOT DILUTE

**Uses**

For pultrusion of polyester, and vinyl ester resins.

**Typical Properties**

Effective Ingredients	100%
Color	Light Amber
Specific Gravity	0.966
pH	6.8
Viscosity	Ca. 300 cps @ 25°C
Shelf Life	1 yr. minimum in original closed container

**Instructions for Use**

For best results, laboratory tests or pre-production trials should determine the optimum addition level. Typical addition level in polyester or vinyl pultrusion is 10-15 parts/1000 by weight (1% - 1.5%) by resin weight (excluding fillers), although small or simple profiles may be achieved with lower addition levels.

High amounts of filler loadings or more difficult profiles may require higher addition levels. Additional information on conducting pre-production trials is available in AXEL's Technical Guide: Testing IMRs in Thermoset Resins.

**Mixing:** For polyester or vinyl-ester resins, mix any and all fillers in the resin *prior* to adding the AXEL INT-PUL29 lubricant. Typically, the catalysts are added after the lubricant. Also, do not mix the lubricant directly with low profile additives. Any LPA's should be added to the resin and mixed thoroughly prior to adding the INT-PUL29 lubricant.

XTEND, MoldWiz & PasteWiz are registered trademarks of Axcel Plastics Research Laboratories.

This information is supplied for technically skilled professionals working at their own risk. AXEL believes the information to be accurate, although the Company assumes no liability in the validity of this information for any specific process or application. Moreover, AXEL will assume no liability from any direct and/or consequential damages of any kind that may arise from the use or non use of AXEL products or information supplied by the Company or its appointed representatives.

05/13/2013